

A
x1


B
x4

C
x4

D
x1

E
x2

F
x3




Adjustable Floor Stand for
PULSE M, PULSE FLEX and PULSE FLEX P130


1





2





3



PULSE FLEX P130





PULSE M



4


PULSE FLEX






Adjustable Floor Stand for
PULSE M, PULSE FLEX and PULSE FLEX P130

PULSE FLEX P130





PULSE FLEX



5

PULSE M



6

