

When the projector's Password Protect is activated, people who do not know the password cannot use the projector to project images even if the projector power is on. Furthermore, the user's logo that is displayed when you turn on the projector cannot be changed. This acts as an anti-theft device as the projector cannot be used even if it is stolen.

🖱️ User's Guide "Managing Users (Password Protect)"

Follow the steps below to stick the password protect sticker on the projector as a further theft deterrent.

Attention

- Do not cover the air vent on the base of the projector, or the air exhaust or air intake vents.
- Do not stick it onto parts that are subject to increases in temperature, such as the lamp cover.
- Do not stick it over any warning labels.

Sticking the Password Protect Sticker

- 1** Print out this page.
We recommend printing on commercially available self adhesive paper.
- 2** Cut out the following password protect sticker along the dotted line.



- 3** Stick the password protect sticker onto the projector.